



INSTALLATION INSTRUCTIONS SPEED CONTROL PACKAGE

1988
REAR WHEEL DRIVE PASSENGER CAR

Please read these instructions completely prior to attempting to install this speed control package on a vehicle to familiarize yourself with the components and their locations. References to the Service Manual may be required for adjustments, fastener torques and diagnosis.

**DISCONNECT THE NEGATIVE BATTERY CABLE
BEFORE YOU BEGIN**

PASSENGER COMPARTMENT

1. **SPEED CONTROL SWITCH INSTALLATION**

- Remove the shaft cover and discard.
- Install the speed control switch and torque fasteners to 24 in. lbs. SEE FIGURE 1.

2. **STEERING COLUMN SPEED CONTROL SWITCH WIRING**

- Lift turn signal lever up. Attach speed control connector and wiring to a guide wire SEE FIGURE 2. Route the feed wire and switch wiring down through the column and wiring trough. Four new trough retaining buttons are provided should removal of the trough be required.

CAUTION: Because of potential safety hazards, caution should be observed when routing wires through column to avoid chafing or grounding.

- Insert the speed control switch connector into the mating connector on the vehicle harness located close to the steering column.

SWITCH INSTALLATION

FIGURE 1

