


**ELECTRONIC IGNITION SYSTEM PRIMARY CIRCUIT DIAGNOSIS**



\*ALL TESTS AND REPAIRS ARE DESCRIBED IN APPROPRIATE SECTION OF SERVICE MANUAL  
 \*\* REFER TO "TESTING IGNITION SYSTEM" FOR INSTALLING TESTERS